

Addendum to the Power Macintosh Processor Upgrade Card Installation Instructions

In the enclosed installation manual, a step is missing from the instructions for installing the Power Macintosh Processor Upgrade Card in a Power Macintosh 7500 or 7600 computer. Complete the following step before step 11 on page 8:

Install the grounding clip.

The clip slides over one wall of the top chassis. Make sure the grounding clip also touches the processor card heat sink.

