

# **Swapping processor upgrade cards**

This addendum provides important information about different processor upgrade cards and helps you know which ones can be installed in specific Macintosh computers you may have.

### What to do with a used processor card

If you removed a 120 megahertz (MHz) processor card from your Power Macintosh 8500 or 9500 series computer, you can use it to upgrade the processor in a Power Macintosh 7500/100 computer. Follow the instructions in Chapter 1 of the manual *Power Macintosh Processor Upgrade Card*.

As long as you have not installed the used card in another computer, be sure to store the card in an antistatic bag.

## **Technical specifications**

### 120 MHz 604 processor card

- 120 MHz
- built-in floating point unit
- 40 MHz system bus

### 132 MHz 604 processor card

- 132 MHz
- built-in floating point unit
- 44 MHz system bus