

About Your AirPort Card

Includes information about
the AirPort Card and AirPort software



About Your AirPort Card

With the AirPort Card installed in your computer, you can do the following:

- Access an AirPort network at home, school, or work and use it to browse the Internet, send and receive email, and more.
- Set up a Computer-to-Computer network between two or more AirPort-equipped computers, which you can use to transfer files or play multiplayer games.
- Set up an AirPort network using an external device called an "AirPort Base Station," available from your Apple-authorized dealer or the Apple Store at www.apple.com/store
- Set up an AirPort network using your computer as a base station. Using the AirPort software base station feature, your computer can provide Internet access to other AirPort-equipped computers.

Important If you purchased the AirPort Base Station at the same time as your AirPort Card, install the AirPort Card and then set up the AirPort Base Station using the instructions provided with the base station. The AirPort Setup Assistant described in this booklet is the same one used to set up the AirPort Base Station. To set up the AirPort Base Station and configure your computer to access the AirPort network it creates, you only need to use the AirPort Setup Assistant once.

anywhere in your home, classroom, or small office. Instead of using traditional cables to create a network, AirPort uses wireless local area network (LAN) technology to provide wireless communication between computers.

How AirPort Works

In a traditional network, computers are connected through a series of wires that transfer information among them. With AirPort, data is transferred between computers over a wireless network using radio waves.

There are two ways to create a wireless network. You can use an AirPort-equipped computer to create a temporary Computer-to-Computer network, which other AirPort computers within range can join. Or you can create a more permanent wireless network using a base station. In this kind of network, all wireless communication goes through the base station to other computers on the network or to the Internet.

How AirPort Provides Wireless Internet Access

The following are ways that you can use AirPort technology to provide Internet access to AirPort-equipped computers:

- Connect an AirPort Base Station (available from your Apple-authorized dealer or the Apple Store at www.apple.com/store) to an existing network that already has Internet access, such as in a school or small office.
- Connect a telephone line, cable modem, or DSL modem to an AirPort Base Station. The AirPort Base Station establishes an Internet connection and also creates a wireless network through which multiple computers can access the Internet.
- Share the Internet connection of a single AirPort-equipped computer with other computers by enabling the AirPort software base station feature. When AirPort-equipped computers need to access the Internet, all information passes through the computer with the Internet connection.

Note: To use AirPort to access the Internet, you must have an account with an Internet service provider (fees may apply). Some Internet service providers (ISPs) are not currently compatible with AirPort, including America Online. Though some ISP accounts that use connection scripts or terminal login windows are not supported, certain AirPort-compatible connection scripts have been provided and can be selected in the AirPort Setup Assistant or AirPort Admin Utility.

For more information on using AirPort with your Internet account, contact your ISP or go to the Apple Tech Info Library at til.info.apple.com

Step 1: Do You Need to Install the AirPort Card?

If you ordered your AirPort Card with your new computer, the AirPort Card is already installed. If the AirPort Card came in a separate kit, you need to install it yourself. Instructions for installing the AirPort Card are in the manual that came with your computer. You can also find them on the Apple Support Web site at www.apple.com/support

The AirPort Card is not a standard PC Card. If you are installing an AirPort Card in a PowerBook computer, follow the installation instructions in the manual that came with your PowerBook. Don't install the AirPort Card in your PowerBook's PC Card slot.

Warning The AirPort Card has been designed so that you can install it yourself. If, after reading the instructions, you feel uncomfortable about installing the card, you can have an Apple-authorized service provider install it for you. If you follow the instructions, you should not be concerned about damaging your computer. However, if you do attempt to install the AirPort Card yourself, any damage you may cause to your equipment will not be covered by the limited warranty on your computer. See an Apple-authorized dealer or service provider for additional information about this or any other warranty question. Consult the service and support information that came with your computer for instructions on how to contact an Apple-authorized service provider or Apple for service.

Do I need to know the AirPort ID of my AirPort Card?

If you are going to use your computer on a large AirPort network, such as in a school or office, you may need to provide the AirPort ID (sometimes known as the MAC address) of your AirPort Card to your network administrator. The AirPort ID is a 12-digit alphanumeric value printed on a label on the AirPort Card. You can also find your AirPort ID by opening the AirPort application, located in the Apple () menu. Your network administrator can use the AirPort ID to provide an extra level of security for the network.

Do I need to install an AirPort antenna?

No. The antenna used by the AirPort Card is already built into your computer.

- 1 Install the AirPort Card in your computer.
- 2 Skip the rest of the steps in this booklet and set up the AirPort Base Station using the instructions provided with the base station.
The AirPort Setup Assistant described in the next step is the same one used to set up the AirPort Base Station. To set up the AirPort Base Station and configure your computer to access the AirPort network, you only need to use the AirPort Setup Assistant once.


Step 3: Set Up Your Computer to Use AirPort

If you are going to use your computer with an AirPort network that is already established (such as in a school or office) or you want to set up your computer to be a software base station, do the following:

- 1 Install the AirPort software using the CD provided with the AirPort Card.
 - If you ordered the AirPort Card with your new computer, the AirPort software is already installed on your computer. You may not have a separate AirPort CD.

Note: To make sure that your computer has the latest version of the AirPort software installed, check the Apple AirPort Web site at www.apple.com/airport

- 2 Open the AirPort Setup Assistant, in the Assistants folder on your hard disk. Select "Set up your computer to join an existing wireless network" to configure your computer to access an existing AirPort network. Select "Set up your computer to be an AirPort Software Base Station" to have your computer create an AirPort network that other AirPort-equipped computers can use to access the Internet.



completely inserted into the AirPort Card slot. Make sure the AirPort antenna is securely connected to the card and the connector on the other end of the card is firmly inserted into the connector in the AirPort Card slot.

If you are unable to detect the network you want to connect to

- Make sure that you are in range of an AirPort Base Station. The typical range for AirPort communication is up to 150 feet (45 meters) in any direction from the base station.
- Try to move away from possible sources of interference, such as microwave ovens and metal walls, that may be preventing you from connecting to the network. For a complete list of sources of interference, open the Help menu and choose Help Center, then search for "AirPort interference."

Additional AirPort Software

In addition to the Setup Assistant, you can use the following software to work with AirPort:



AirPort

Use the AirPort application, located in the Apple () menu, to switch between AirPort networks, connect and disconnect your AirPort Base Station from the Internet, set up a Computer-to-Computer network, and adjust settings for an AirPort software base station.



AirPort Admin Utility

The AirPort Admin Utility, located in the AirPort folder inside the Apple Extras folder, is an advanced tool used to set up and manage the AirPort Base Station. Use the AirPort Admin Utility to adjust network, routing, and security settings, and other advanced options.



AirPort Control Strip module

You can use the Control Strip to switch quickly between AirPort networks, monitor the signal quality of the current network, and turn AirPort on and off.

Additional Information on AirPort

For more information on AirPort, see AirPort Help in the Help Center, available in the Help menu. There you will find information on setting up an AirPort network using an AirPort Base Station, editing base station settings, avoiding sources of interference, locating additional information on the Internet, and more.

For information on specific items in any of the AirPort applications, choose Show Balloons from the Help menu. Then point to the item that interests you.

For in-depth information on configuring AirPort networks, see the "Designing AirPort Networks" document, located in the AirPort folder inside the Apple Extras folder on your hard disk, or on the CD that came with your AirPort Card.

In addition to AirPort Help, Balloon Help, and "Designing AirPort Networks," you can find more information at the following Apple Web sites:

- The Apple AirPort Web site at www.apple.com/airport
- The Apple Support Web site at www.apple.com/support

- Range: Up to 150 feet (45 meters) radius from the base station in typical indoor use (varies with building)
- Frequency Band: 2.4 gigahertz (GHz)
- Radio Output Power: 15 dbm (nominal)
- Standards: Compliant with 802.11 HR Direct Sequence Spread Spectrum (DSSS) 11 Mbps standard and 802.11 DSSS 1 and 2 Mbps standard

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See instructions if interference to radio or television reception is suspected.

Radio and Television Interference

The equipment described in this manual generates, uses, and can radiate radio-frequency energy. If it is not installed and used properly—that is, in strict accordance with Apple's instructions—it may cause interference with radio and television reception.

This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in Part 15 of FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

You can determine whether your computer system is causing interference by turning it off. If the interference stops, it was probably caused by the computer or one of the peripheral devices.

If your computer system does cause interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the computer to one side or the other of the television or radio.
- Move the computer farther away from the television or radio.
- Plug the computer into an outlet that is on a different circuit from the television or radio. (That is, make certain the computer and the television or radio are on circuits controlled by different circuit breakers or fuses.)

If necessary, consult an Apple-authorized service provider or Apple. See the service and support information that came with your Apple product. Or, consult an experienced radio/television technician for additional suggestions.

Important Changes or modifications to this product not authorized by Apple Computer, Inc., could void the FCC Certification and negate your authority to operate the product.

This product was tested for FCC compliance under conditions that included the use of Apple peripheral devices and Apple shielded cables and connectors between system components. It is important that you use Apple peripheral devices and shielded cables and connectors between system components to reduce the possibility of causing interference to radios, television sets, and other electronic devices. You can obtain Apple peripheral devices and the proper shielded cables and connectors through an Apple-authorized dealer. For non-Apple peripheral devices, contact the manufacturer or dealer for assistance.

Responsible party (contact for FCC matters only): Apple Computer, Inc., Product Compliance,
1 Infinite Loop M/S 26-A, Cupertino, CA 95014-2084, 408-974-2000.

Exposure to Radio Frequency Energy

The radiated output power of the optional AirPort Card is far below the FCC radio frequency exposure limits. Nevertheless, it is advised to use the wireless equipment in such a manner that the potential for human contact during normal operation is minimized.

Industry Canada Statement

This Class B device meets all requirements of the Canadian interference-causing equipment regulations.

Cet appareil numérique de la Class B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Europe—EU Declaration of Conformity

This device complies with the specifications ETS 300 328 and ETS 300 826, following the provisions of the EMC Directive 89/332/EEC.

