

## UPDATE TO GETTING STARTED WITH YOUR MACINTOSH LC 520

### Button Disabler control panel

You can prevent other people from using the sound and screen control buttons on the front of your computer by using the Button Disabler control panel. The disabler will not affect any other buttons on your computer or any buttons on devices connected to the computer.

The Button Disabler control panel is already installed in your Control Panels folder.

To use the Button Disabler control panel:

1. Pull down the Apple (K) menu and choose Control Panels.
2. Double-click the Button Disabler control panel to open it.
3. To turn off the contrast and volume buttons, click the Disable Buttons box until an "X" appears.

The buttons remain off until you turn them on again (by clicking the Disable Buttons box to remove the "X").

By the way: If you want to use a password to control access to the Button Disabler control panel, consider using At Ease, an application program available through an Apple-authorized dealer.

### Reinstalling the control panel

If you can't find the Button Disabler control panel, you can install it from the CD Install Me First disc that came with your computer.

To reinstall the Button Disabler control panel:

1. Start up your computer from the internal hard disk in your computer.
2. Insert the disc CD Install Me First into your computer's CD drive.
3. Open the Button Disabler folder on the CD disc.
4. Drag the Button Disabler icon to the System Folder on your hard disk.

A message tells you that the files need to be put in the Control Panels folder.

Note: Make sure you don't drag the Button Disabler icon to the System Folder on the CD Install Me First disc.

5. Click OK.

Now you can use the control panel as described in this update.