




Before You Use Your PowerBook 2400c Computer

Before using your Macintosh PowerBook 2400c for the first time, it is important that you plug in the power adapter provided with your computer. If the PowerBook battery has drained during shipping or storage, your computer will not start up until the power adapter is connected. Follow the instructions in Chapter 1, “Setting Up,” of your user’s manual to plug in your power adapter and turn the computer on.

If the computer doesn’t make a sound when you press the Power key, check to make sure the power adapter is properly connected and that power is being supplied to the computer. If your computer still doesn’t make a sound when you press the Power key, press the reset button (marked with ) on the back of the computer. Once the battery has charged, you should be able to use the Power key to start up normally.

