



Technical Information

for the Workgroup Server 6150/66

 Apple Computer, Inc.

This manual is copyrighted by Apple or by Apple's suppliers, with all rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Apple Computer, Inc. This exception does not allow copies to be made for others, whether or not sold, but all of the material purchased may be sold, given, or lent to another person. Under the law, copying includes translating into another language.

The Apple logo is a registered trademark of Apple Computer, Inc. Use of the "keyboard" Apple logo (Option-Shift-K) for commercial purposes without the prior written consent of Apple may constitute trademark infringement and unfair competition in violation of federal and state laws.

Every effort has been made to ensure that the information in this manual is accurate. Apple is not responsible for printing or clerical errors.

© Apple Computer, Inc., 1995
1 Infinite Loop
Cupertino, CA 95014-2084
(408) 996-1010

Apple, the Apple logo, Apple SuperDrive, and Macintosh are trademarks of Apple Computer, Inc., registered in the United States and other countries.

Apple Desktop Bus, AudioVision, and GeoPort are trademarks of Apple Computer, Inc.

NuBus is a trademark of Texas Instruments.

PowerPC is a trademark of International Business Machines Corporation, used under license therefrom.

Simultaneously published in the United States and Canada.

Mention of third-party products is for informational purposes only and constitutes neither an endorsement nor a recommendation. Apple assumes no responsibility with regard to the performance or use of these products.

Technical Information for the Workgroup Server 6150/66

This booklet contains the following technical information about your Workgroup Server 6150/66:

- Expanding your server
- Specifications

WARNING If you have a problem with your server and nothing in the manuals that came with the server solves the problem, consult the service and support information that came with your server for information on how to contact an Apple-authorized service provider or Apple for assistance.

Expanding your Workgroup Server 6150/66

Your Workgroup Server 6150/66 was designed to grow with your needs—you can add new capabilities or improve its performance as you wish. You can plug in a number of external devices into its ports. You or your dealer can also install a number of enhancements within the case that houses the computer.

Apple recommends that you have the following equipment installed by an Apple-authorized dealer:

- additional dynamic random-access memory (DRAM), up to 72 megabytes (MB)

You can install the following yourself:

- one processor-direct slot (PDS) card or one NuBus™ card for the expansion slot

Choosing the right components

As explained in the next two sections, you must make sure each component you add is compatible with your server and does not exceed its maximum power allowance.

Compatibility

Your dealer or the manufacturer of a component can provide compatibility details. However, you might find these points useful:

- In general, NuBus cards designed for older Macintosh computers also work with the Workgroup Server 6150/66. The card cannot exceed 7 inches in length; it requires an adapter for installation.
- The Workgroup Server 6150/66 uses 32-bit-wide, 72-pin random-access memory (RAM) Single Inline Memory Modules (SIMMs), which must be installed in matched pairs (for example, two 8 MB SIMMs). Your server's SIMMs are fast-paged mode, 80-nanosecond RAM access time or faster. SIMMs from older Macintosh computers may not be compatible. For more detailed information, see "RAM Configurations" later in this booklet.

Power allowances

The Workgroup Server 6150/66 meets Apple's NuBus power specifications. Check the information that came with your expansion card to make sure the card does not exceed these specifications.

For more detailed information, see "Expansion Cards and Devices" later in this booklet.

Specifications

This section lists the hardware specifications for the Workgroup Server 6150/66.

Main unit

Processor

- PowerPC 601 at 66 megahertz (MHz)
- 32 kilobytes (KB) of on-chip cache

Memory

- A minimum of 8 MB of DRAM, expandable to a maximum of 72 MB
- 4 MB read-only memory (ROM)
- 256 bytes of nonvolatile parameter memory
- 256 KB of static RAM used as a Level 2 cache for the PowerPC processor

Disk drives

- Apple SuperDrive 1.4 MB high-density floppy disk drive
- Internal Apple SCSI hard disk drive ($\frac{1}{3}$ -height)
- Internal 5.25-inch quadruple-speed CD-ROM player (600 KB-per-second transfer rate)

A combination of up to seven internal and external SCSI devices can be used.

Monitors

Table 1 shows the image size for monitors connected to the high-density monitor port, along with the number of colors or grays supported.




Table 1 Colors or grays supported*

Monitor	Resolution	Colors or grays
12" Color	512 x 384	thousands
13" Color	640 x 480	thousands
15" Portrait	640 x 870	256
16" Color	832 x 624	256
VGA	640 x 480	256

*Larger monitors and additional colors can be supported with the addition of video RAM (VRAM), which can be added only by means of an expansion card.

Audio system

- Custom sound circuitry, including stereo generator (D/A) capable of driving stereo miniplug headphones or audio equipment, and stereo sampling hardware (A/D) for recording samples
- 16-bit stereo in and out
- Sample rates of 44.1 and 22.05 kilohertz (kHz)
- *Input line level:* 2 volts peak-to-peak (Vpp) nominal, into 6.5 kilohm (k Ω) impedance
- *Output line level:* 2.2 VPP nominal, into 1 k Ω impedance
- *Input through output signal-to-noise ratio (SNR):* > 86 decibels (dB) with no audible discrete tones
- *Bandwidth:* 10 hertz (Hz)–19 kHz (+/- 2 dB) at 44.100 kHz sample rate
- *Total harmonic distortion plus noise (THD+N):* Less than 0.06%; measured 30 Hz–16 kHz with a 2-Vpp sine wave input

Interfaces

- One Apple Desktop Bus (ADB) port supports a keyboard, mouse, and other devices daisy-chained through a low-speed, synchronous serial bus (recommended maximum of three devices).
- High-density monitor port supports color and monochrome monitors of various sizes and resolutions. Apple AudioVision monitors are supported directly; other monitors require a monitor cable adapter (included with the server).
- Internal expansion slot supports one processor-direct slot (PDS) expansion card or one NuBus expansion card, both of which require an adapter. Any expansion card installed in your Workgroup Server 6150/66 must be no more than 7 inches in length.
- Two RS-232/RS-422 GeoPort serial ports, 230.4 kilobit (Kbit)-per-second maximum (up to 2.048 megabit (Mbit)-per-second if clocked externally).
- Built-in Apple Ethernet AAUI connector for connecting to high-speed Ethernet networks.
- SCSI interface supports up to seven SCSI devices (internal and external).
- Sound output port for stereo compact disc audio and stereo computer-generated sound.
- Sound input port for stereo sound input.

A/C line input

- *Line voltage:* 100–240 volts AC, RMS single phase, automatically configured
- *Frequency:* 50–60 Hz
- *Power:* 175 watts maximum, not including monitor power

A/C line output

- *Output receptacle:* 100–240 volts AC, RMS (determined by actual input voltage), 3 amperes (amps) maximum

DC power

- 86 watts maximum

Current type	Total
+5 V	11.6 A
+12 V	2.5 A
-12 V	0.5 A

Clock/Calendar

- CMOS custom chip with long-life lithium battery

Keyboard

- Supports all Apple ADB keyboards

Mouse

- Supports all models of the Apple ADB mouse

RAM configurations

RAM is provided both on the logic board (8 MB) and in packages called Single Inline Memory Modules (SIMMs).

Your server can work with any of several DRAM configurations, depending on the density of the DRAM chips that are mounted on the SIMMs. The 72-pin SIMMs used in the Workgroup Server 6150/66 come in sizes of 4, 8, 16, and 32 MB.

IMPORTANT The SIMMs must be installed in matched pairs (for example, two 8 MB SIMMs).

Your server can have a maximum of 72 MB of memory.

Note: 640K of DRAM is used for screen memory in place of video RAM (VRAM) to support monitors connected to the high-density monitor port. VRAM can be added only by means of an expansion card.

IMPORTANT The SIMMs should be 72-pin fast-paged mode, 80-nanosecond (ns) RAM access time or faster. The slower 100 ns, 120 ns, and 150 ns SIMMs will not work reliably in the Workgroup Server 6150/66, and SIMMs from older Macintosh computers may not be compatible. Consult an Apple-authorized dealer or service provider for information and upgrades.

WARNING To avoid damage to your server, Apple Computer recommends that only an Apple-authorized dealer or service provider install additional RAM. If you attempt to install additional RAM yourself, any damage you may cause to your equipment will not be covered by the limited warranty on your server. See an Apple-authorized dealer or service provider for additional information about this or any other warranty question.

Power requirements

Apple Desktop Bus (ADB)

- Maximum power draw for all ADB devices: 500 milliamperes (mA)
- Mouse draws up to 10 mA
- Keyboard draws 25–80 mA (varies with keyboard model used)

Note: It is recommended that you connect no more than three ADB devices to the Workgroup Server 6150/66.

Audio and telecommunications devices

This table shows the power allowances for external devices connected to input ports.

Device	Voltage	Current	Power
Microphone	+5 V	20 mA	100 milliwatt (mW)
GeoPort Telecom Adapter	+5 V	500 mA	2.5 W

Expansion cards and devices

If you add a PDS or NuBus expansion card to your server, or if you replace any of the built-in storage devices with a 3.5- or 5.25-inch SCSI device, make sure the component doesn't exceed its maximum power allowance from the different voltage sources. Follow these guidelines.

Device	Voltage	Current	Power
NuBus or PDS card	+5 V	1.22 A	6.1 W*
	+12 V	0.175 A	2.1 W
	-12 V	0.150 A	1.8 W
3.5-inch or 5.25-inch device (per device)	+5 V	0.5 A	2.5 W
	+12 V	0.8 A	9.6 W
	+12 V	1.5 A peak†	—

*The power allocation to +5 volts can be higher than 6.1 watts as long as the total power allowance for the expansion card does not exceed 10 watts.

† Peak power is for startup only and must not occur in normal operation.

Size and weight

Weight	Height	Width	Depth
Main unit			
6.4 kg*	85 mm	415 mm	397 mm
14 lb.*	3.4 in.	16.3 in.	15.6 in.
Mouse			
0.10 kg	33 mm	61.7 mm	107.3 mm
4 oz.	1.3 in.	2.4 in.	4.2 in.

*Exact weight varies depending on type of hard disk installed.

Environment

Operating temperature

- 10° C to 40° C (50° F to 104° F)

Storage temperature

- -40° C to 47° C (-40° F to 116.6° F)

Relative humidity

- 5% to 95% (noncondensing)

Altitude

- 0 to 3048 m (0 to 10,000 ft.)

Apple Computer, Inc.

1 Infinite Loop
Cupertino, California 95014-2084
(408) 996-1010

030-7043-A
Printed in U.S.A.